


Product manual



How to check the power level:

This portable power bank has 4 power level indicators which enable you to check the remaining power conveniently. You can check the remaining power level by pressing the power button, the LED status shown in the above illustration.

Information:

- To connect other devices, please read safety instructions in detail carefully from the user manual.

Please choose a suitable connector according to your device and identify the input/output port of the power bank.

Do not use the power bank to charge other devices while charging the power of the power bank.

If not in use, you are suggested to disconnect the charger or output cable.

- If the power bank's output voltage is lower than the rated voltage or working voltage of your device, the device may not be charged. If the power bank's output voltage is higher than the rated voltage or working voltage of your device, it might overcharge your device or damage the power bank itself, even damage your device.

Safety instructions:

- Do not throw the power bank into fire or try to heat it up. In such situations it might burn, explode, or release toxic gas.
- Do not connect positive and negative pins directly.
- Do not store the power bank with other metallic materials.
- Do not try to open up the power bank or break with intention.
- Do not throw the battery into water or allow it to get wet.

Storage and Maintenance:

If you do not use the power bank for a long time, please proceed according to these instructions once a year to maintain its normal functions: First fully charge the power bank, then discharge it through charging another device, then recharge it with half capacity and keep it in a cool, dry place.

- It is recommended to do a complete charge and discharge every 3 months to ensure long-lasting status of the internal battery cells.